






ASSEMBLING INSTRUCTION

MT-3515

PART LIST


1  x1	2  x1	3  x2	4  x2	5  x3	
6  x1	7  x1	8  x1	9  x1	10  x1	
11  x1	12  x1	13  x1	14  x1	15  x1	
S1  x1	S2  12 mm x1	S3  15 mm x1	S4  21 mm x7	S5  28 mm x8	S6  x1

ADULT ASSEMBLE


ASSEMBLY INSTRUCTION

MT-3515


STEP 2




STEP 3



STEP 1



STEP 4



STEP 5

